

M.I.C.M. - C.N.I.A.R.

INTreprinderea de CONSTRUCTII AERONAUTICE

2200 B R A S O V

This bulletin is applied by the users to gliders under servicing up to serial no. 163 inclusive except the gliders serial no. 115, 119, 128, 140, 141, 145, 144, 149, 146, 147, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161 to which the modification was applied by the manufacturing plant;

To gliders beginning with serial no. 164 the modification is applied by the manufacturing plants.

MANDATORY SERVICE BULLETIN

This bulletin is applied until the 1st of March 1979 and it replaces the bulletin IS-28B2/EO-7

B) Reason

Additional indications concerning the wing locking.

Approved by : Department of Civil Aviation
applying with no. 345 / 8.01.1979

Product : Exported IS-28B2 glider no. 28B, PO3/885/888 for the gliders already mentioned.

Object : Additional indications concerning the wing locking.

Compliance : Revision Record Card no. 657.

To gliders under manufacturing this bulletin is applied as an except modification. To gliders under servicing it is applied by the users not later than the 1st of March 1979.

B) Material-Cost and Availability

Materials necessary to apply this bulletin are specified in chapter 3A and delivered by the manufacturing plant together with this service bulletin and instructions to the users.

DATE: 04.01.1979

IS-28B2/EO-7

Page 1/5

DATE: 04.01.1979

IS-28B2/EO-7

Page 2/5

1. PLANNING INFORMATION

A. Applicability

This bulletin is applied by the users to gliders under servicing up to serial no. 163 inclusive except the gliders serial no. 115, 119, 128, 140, 141, 143, 144, 145, 146, 147, 150, 151, 152, 153, 154, 155, 156, 157, 158, 160, 161 to which the modification was applied by the manufacturing plant.

To gliders beginning with serial no. 164 the modification is applied by the manufacturing plant.

This bulletin will be applied until the 1st of March 1979 and not later.

B. Reason

Additional indications concerning the wing locking.

C. Description

Applying the warning placard part no. 28B.F03.882/887 by gluing it on the wing spar in the junction area for exported gliders and part no. 28B.F03.883/888 for the gliders existing in Romania.

D. Compliance

Revision Record Card no. 657.

E. Accomplishment

To gliders under manufacturing this bulletin is applied as current modification. To gliders under servicing it is applied by the users not later than the 1st of March 1979.

F. Material-Cost and Availability

Materials necessary to apply this bulletin are specified in chapter 3A and delivered by the manufacturing plant together with this service bulletin. Application belongs to the users.

DATE: 04.01.1979

IS-28B2/E0-7
Page 2/5

C. Supply Indications

The placards are delivered by the manufacturing plant together with this bulletin.

4. IDENTIFICATION

The modifications application is mentioned in the glider logbook.

5. APPENDICES

Warning placards according to chapter 3.A from the Mandatory Service Bulletin IS-28B2/E0-7.


Pages 02, 03B, 20A, 2.11.A, 6.0/3A and 6.4.1A issue 3A - December 1978.

DATE: 04.01.1979

IS-28B2/E0-7
Page 4/5

MANDATORY SERVICE BULLETIN
I.S. 28B2 / EO-7

APPENDIX I



REVISION RECORD CARD

Part no.	Amended page	Revision nature	Data		Signature
			of approval	of insertion	
1.	6.6.1.A 03.A	Tail junction bolts	04.12.78	08.12.78	
2.	03B; 2.0.A; 2.11.A; 6.0/3.A; 6.4.1.A	Additional indications concerning the junction lock	09.01.79	12.01.79	
3.	A.1.1 A.1-A.1.14	Dit tel radio installation (optional)	11.05.79	14.05.79	
4.	0.3.C; 2.1.A; 5.5.A; 6.14.A; 6.15.A; 6.46.A; 6.47.A; 6.48.A;	Additional indications	26.06.79	28.06.79	
5.	0.3.D; 2.3.A; 2.5.A; 2.7.A; 6.46.B;	Indications for light pilots	31.01.1980		
6.	0.3.E 1.0.A 1.5.A	Introducing of flush hinges for the glider serial no. 231 and subs.	12.02.80	19.02.80	
7.	A.2.1; A.2.2.	Air brake on lower side (optional)			

3rd E ISSUE - NOVEMBER 1979

Page 0.2E

FLIGHT AND MAINTENANCE MANUAL IS-28B2

VALID PAGES LIST

Page no.	Issue
0.1	3 rd issue : april 1978
2 0.2; 0.3	3 rd A issue: december 1978
1.0 to 1.8	3 rd issue: april 1978
2 2.0A	3 rd A issue: december 1978
2.1 to 2.10	3 rd issue: april 1978
2 2.11.A	3 rd A issue: december 1978
3.0 to 3.1	3 rd issue: april 1978
4.0 to 4.12	3 rd issue: april 1978
5.0 to 5.5	3 rd issue: april 1978
6.0 to 6.49	3 rd issue: april 1978
1 6.6.1.A	3 rd A issue: november 1978
2 6.4.1.A	3 rd A issue: december 1978


C H A P T E R 2LIMITATIONS

C o n t e n t s :


	Page
2.1. Certification	2.1.
2.2. Speed limitations	2.1.
2.3. Airspeed indicator marking	2.2.
2.4. Load factors and limit weights	2.2.
2.5. Maximum weights	2.2.
2.6. Balance	2.2.
2.7. Accepted evolutions	2.4.
2.8. Special instructions	2.4.
2.9. Placards	2.4.
2.9.1. Limitations placard	2.4.
2.9.2. Aerobatic manoeuvres speed placard	2.7.
2.9.3. Warning placard for max.luggage into the luggage compartment	2.8.
2.9.4. Controls identification placards	2.8.
2.9.4.1. Placards for air brake and wheel brake control	2.8.
2.9.4.2. Placards for flap control	2.9.
2.9.4.3. Placards for trim tab control	2.9.
2.9.4.4. Placards for landing gear retraction control	2.9.
2.9.4.5. Placards for canopy opening and jettison	2.10.
2.9.4.6. Placard for release control	2.10.
2.9.4.7. Placard for the front air scoop control	2.10.
2.9.4.8. Placard indicating the direction for wing main junction lock	2.10.
2.9.4.9. Placard indicating the wing junction mounting	2.11A.
2.9.4.10. Placard indicating the wing junction locking	2.11A.
2.9.4.11. Other markings	2.11A.

2.9.4.9. Placard indicating the wing junction mounting (red coloured)

2



2.9.4.10. Placard indicating the wing junction locking (red coloured)



2.9.4.11. Other markings

- near the landing gear wheel : 25 atm (35 psi)
- on landing gear oleo-pneumatic shock-absorber : 60-65 atm (840-910 psi)
- near the tail skid wheel : 25 atm (35 psi)
- on rudder, elevator and flaps DO NOT PUSH
- leveling points and static pressure sources are marked.

Drawings :	Page
Fig. 6-1 Fuselage-wing junction detail	6.3
Fig. 6-2 Wing approach device	6.4
2 Fig. 6-2.1 Main junction tightening	6.4.1.A
Fig. 6-3 Tails junction details	6.6
Fig. 6-4 Manoeuvring wheel mounting	6.8
Fig. 6-5 Greasing points	6.12
Fig. 6-6 Releaser control	6.16
Fig. 6-7 Landing gear	6.18
Fig. 6-8 Landing gear retraction	6.19
Fig. 6-9 Landing gear retraction control (for gliders having a serial no. up to 31)	6.21
Fig. 6-10 Landing gear shock-absorber	6.22
Fig. 6-11 Inspection covers location	6.24
Fig. 6-12 Elevator control	6.26
Fig. 6-13 Aileron control	6.27
Fig. 6-14 Rudder control	6.28
Fig. 6-15 Trim tab control	6.30
Fig. 6-16 Air brake and wheel brake control	6.31
Fig. 6-17 Wheel brake control (for gliders with serial no. up to 54)	6.33
Fig. 6-18 Air brake control (for gliders with serial no. up to 54)	6.34
Fig. 6-19 Flap control	6.35
Fig. 6-20 Flap control (for gliders with serial no. up to 30)	6.36
Fig. 6-21 Instruments connection diagram	6.37
Fig. 6-22 Turn and Bank Indicator electrical diagram	6.39
Fig. 6-23 Total energy variometer system	6.41

C H A P T E R 2LIMITATIONS

C o n t e n t s :	Page
2.1. Certification	2.1.
2.2. Speed limitations	2.1.
2.3. Airspeed indicator marking	2.2.
2.4. Load factors and limit weights	2.2.
2.5. Maximum weights	2.2.
2.6. Balance	2.2.
2.7. Accepted evolutions	2.4.
2.8. Special instructions	2.4.
2.9. Placards	2.4.
2.9.1. Limitations placard	2.4.
2.9.2. Aerobatic manoeuvres speed placard	2.7.
2.9.3. Warning placard for max. luggage into the luggage compartment	2.8.
2.9.4. Controls identification placards	2.8.
2.9.4.1. Placards for air brake and wheel brake control	2.8.
2.9.4.2. Placards for flap control	2.9.
2.9.4.3. Placards for trim tab control	2.9.
2.9.4.4. Placards for landing gear retraction control	2.9.
2.9.4.5. Placards for canopy opening and jettison	2.10.
2.9.4.6. Placard for release control	2.10.
2.9.4.7. Placard for the front air scoop control	2.10.
2.9.4.8. Placard indicating the direction for wing main junction lock	2.10.
2.9.4.9. Placard indicating the wing junction mounting	2.11A.
2.9.4.10. Placard indicating the wing junction locking	2.11A.
2.9.4.11. Other markings	2.11A.

2




Fig. 6.2.1 Main junction tightening

The junction wrench shall be actuated by hand only (without using extensions).

During the whole tightening operation two persons shall raise and lower the wing extremities simultaneously to facilitate the cones lead in.

Match the wrench into one of the three locking holes indicated by "a" by removing, twisting and inserting it, until the correct position is found (sometimes a slight tightening is also required).

The appended pages 02, 03B, 20A, 2.11.A, 6.0/3A and 6.4.1.A.-
issue 3A - December 1978 shall NOT BE INSERTED in the Flight
and Maintenance Manual 1st and 2nd issue.